

**1. SCOPE**

This work instruction outlines the process for Fitting a DivideUte TrayDivider

**2. Purpose**

To provide step-by-step instructions for safe and correct installation for fitting a DivideUte TrayDivider

**3. Tools & Equipment Needed**

- DivideUte TrayDivider kit (including brackets and hardware)
- Cordless drill and/or Impact driver with appropriate bits
- Tape measure (optional)
- Pencil/marker (optional)
- PPE: safety glasses, gloves

**4. REFERENCES**

- a. <https://www.divideit.com.au/instructions>
- b. <https://www.youtube.com/shorts/akcOezV4fLk> Installation Video

**5. PROCESS****Preparation**

Step No	PROCESS
Hint	Watch the installation video first.
1	Park the vehicle on a flat, stable surface and engage the handbrake.
2	Clear the Ute tray of all cargo and debris.
3	Check the divider kit has all the components and read through the instructions fully.

**Assembling the Divider with steel brackets**

Step No	PROCESS
1	Place the angle brackets into position on the panels and secure with the 16mm screws and washers provided.
2	Stand both the Panels and place them next to the side panel of the tray.
3	Place the joiner in the middle of the panels and use the marks on the top of the panel to locate the Joiner over the panel equal distance from each side of the ute tray and screw the joiner into place.
<b>Hint</b>	Make sure you push the panels out to the side of the ute tray.

**Attaching with steel brackets**

Step No	PROCESS
1	Place the assembled TrayDivider equal distance from the headboard.
<b>Note 1</b>	Check underneath the ute tray to ensure the screws will not penetrate anything except the tray floor.
<b>Note 2</b>	For steel floors you may need to predrill holes with a 3mm drill bit.
2	Screw the bracket into the tray floor with the 25mm screws supplied.
3	For the removable option – Remove the screws in the steel angle brackets and place the minsup clip provided in the top hole.
<b>Hint</b>	Drilling the top hole out to 6mm will help if you have trouble with inserting and removing the minsup clip.

**Storage/Parking Bay installation**

Step No	PROCESS
1	Screw the channels provided into the tray side panel close to the headboard to create a storage slot for the divider when not in use.

**Attaching with Ali Slider Base**

Step No	PROCESS
1	Locate the 600mm or 300mm Ali slider base next to the side panel of the tray equal distance from the headboard.
<b>Note 1</b>	Check underneath the ute tray to ensure the screws will not penetrate anything except the tray floor.
<b>Note 2</b>	For steel floors you may need to predrill holes with a 3mm drill bit.
2	Screw the Ali slider base into the tray floor with the 25mm screws supplied.